

DESPIECE




TABLA DE REFACCIONES

POSICION	REFACCIÓN	BXP6 R150-10	BXP6 R200-14	BXP6 R50-4	BXP6 R75-5	BXP6 R100-7	BXP6 R150-8	BXP8 R200-10	BXP8 R250-12	BXP8 R300-15	BXP8 R75-4	BXP8 R100-5	BXP8 R150-8	BXP11 R300-10	BXP11 R75-2	BXP11 R100-3	BXP11 R150-5	BXP11 R200-6	BXP11 R250-8	BXP14 R75-2	BXP14 R100-3	BXP14 R150-4	BXP14 R200-5	BXP14 R250-7	BXP14 R300-9	CÓDIGO
2	DESCARGA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BXP/DESCAR2"
4	ASIENTO VALVULA CHECK	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BXP6/14-ASCH
9	DIFUSOR ARAÑA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BXP6/14-SPTS
10	BUJE DE SOPORTE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BXP6/14-BINT
14	DISTANCIADOR	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BXP6/14-DIST
16	ARANDELA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BXP6/14-ARAN
17	BUJE DISFUSOR	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BXP6/14-BDIF
18	DIFUSOR	✓	✓	✓	✓	✓	✓																			R-BXP6-DIFUSOR
								✓	✓	✓	✓	✓	✓													R-BXP6-DIFUSOR
														✓	✓	✓	✓	✓	✓							R-BXP6-DIFUSOR
																				✓	✓	✓	✓	✓	✓	R-BXP6-DIFUSOR
22	TAPA DIFUSOR	✓	✓	✓	✓	✓	✓																			R-BXP6-TDIFUSOR
								✓	✓	✓	✓	✓	✓													R-BXP8-TDIFUSOR
														✓	✓	✓	✓	✓								R-BXP11-TDIFUSOR
																			✓	✓	✓	✓	✓	✓	✓	R-BXP14-TDIFUSOR
21	IMPULSOR	✓	✓	✓	✓	✓	✓																			R-BXP6-IMP
								✓	✓	✓	✓	✓	✓													R-BXP8-IMP
														✓	✓	✓	✓	✓	✓							R-BXP11-IMP
																				✓	✓	✓	✓	✓	✓	R-BXP14-IMP
23	SOPORTE INFERIOR	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BXP6/14-SPI
28	COPLER	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BXP6/14-COPLE
30	COLADOR	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BXP6/14-COLADOR
32	SUCCION	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	R-BXP6/14-SUCCION