

DESPIECE




TABLA DE REFACCIONES

POSICIÓN	REFACCIÓN	KIN58-4/1230A	KIN58-5/1127A	KIN58-6/1115	KIN58-6/1230A	KIN58-8/1230A	KIN58-8/1127A	CÓDIGO
1	CABLE CONECTOR	✓	✓	✓	✓	✓	✓	R-KIN-CABLE
5, 6	VÁLVULA CHECK	✓	✓	✓	✓	✓	✓	R-KIN-VALV.CHECK
9	DESCARGA	✓	✓		✓	✓	✓	R-KIN-DESCARGA
				✓				R-KIN-DESCAR-1.25
11	O-RING	✓	✓	✓	✓	✓	✓	R-KIN O-RING-P9
12	CAPACITOR	✓			✓	✓		R-KIN-CAP15MF
			✓	✓				R-KIN-CAP45MF
						✓		R-KIN-CAP50MF
17	BALERO	✓	✓	✓	✓	✓	✓	R-KIN-BAL.INF
					✓		R-KIN-BAL.INF58-8	
18		✓	✓	✓	✓		✓	R-KIN-BAL.SUP
20	SELLO MECANICO					✓	✓	R-KIN-SM.SUP58-8
20	SELLO MECANICO	✓	✓	✓	✓			R-KIN-SM.SUP
21	CANDADO	✓	✓	✓	✓			R-KIN-CANDADO
25	O-RING	✓	✓	✓	✓	✓	✓	R-KIN O-RING-P10
26	TAPA DE CAMARA DE ACEITE					✓	✓	R-KIN-TPS58-8
		✓	✓	✓	✓			R-KIN-TAP.PRT.SELL
29	DIFUSOR	✓	✓	✓	✓			R-KIN-DIF.INF
							✓	R-KIN-DIFUSOR58-4
31	IMPULSOR					✓	✓	R-KIN-IMPULSOR
		✓	✓	✓	✓			R-KIN-IMP.INF
32	TAPA DE DIFUSOR					✓	✓	R-KIN-DIFUSOR
		✓	✓	✓	✓			R-KIN-DIF.SUP
33	IMPULSOR					✓	✓	R-KIN-IMPULSOR
		✓	✓	✓	✓			R-KIN-IMP.SUP
35	FLOTADOR	✓	✓	✓	✓	✓	✓	R-KIN-FLOTADOR
36	CAMISA					✓	✓	R-KIN-CAMISA58-8
		✓	✓	✓	✓			R-KIN-CAMISA
41	BUJE	✓	✓		✓	✓	✓	R-KIN-KIT.BUJE
42	SELLO MECANICO					✓		R-KIN-SM.INF58-8
		✓	✓	✓	✓		✓	R-KIN-SM.INF
44	COLADOR	✓	✓	✓	✓	✓	✓	R-KIN-COLADOR
46	ARANDELA	✓	✓		✓	✓	✓	R-KIN-KITARAND
49	SUCCIÓN	✓	✓	✓	✓	✓	✓	R-KIN-SUCCION
51	PIE DE BOMBA	✓	✓	✓	✓	✓	✓	R-KIN-PIE.BOM