

DESPIECE




TABLA DE REFACCIONES

POSICIÓN	DESCRIPCIÓN	TIDE2-20-3230	TIDE2-30-3230	CÓDIGO SAP
		✓	✓	
1	ADAPTADOR MANGUERA	✓	✓	R-TIDE2-20-AD-MANG
25	COLADOR	✓	✓	R-TIDE2-20-COL
34	SELLO MECANICO	✓	✓	R-TIDE2-SELLO-MEC
35	SELLO DE ACEITE	✓	✓	R-TIDE2-SELLO-ACE
38	DISTANCIADOR	✓	✓	R-TIDE2-DIST-38
45	CUÑA DE ROTOR	✓	✓	R-TIDE2-CUÑA
47	CABLE CONECTOR	✓	✓	R-TIDE2-CABLE
14A	IMPULSOR	✓		R-TIDE2-20-IMP
			✓	R-TIDE2-30-IMP
14B	AGITADOR	✓	✓	R-TIDE2-20-AGITAD
21A	PLACA PROTECTORA	✓	✓	R-TIDE2-20-P-PROTE
31A	BALERO 6204	✓	✓	R-TIDE2-20-BAL-31A
31B	BALERO 6305	✓	✓	R-TIDE2-BAL-31B
36A	ORING	✓	✓	R-TIDE2-ORING36A
36B		✓	✓	R-TIDE2-ORING36B
36C		✓	✓	R-TIDE2-ORING36C
36D		✓	✓	R-TIDE2-ORING36D
37A	JUNTA	✓	✓	R-TIDE2-JUNTA 37A
37B		✓	✓	R-TIDE2-JUNTA 37B
37C		✓	✓	R-TIDE2-JUNTA 37C
41B	BASE DE SELLO MECANICO	✓	✓	R-TIDE2-BASE-SM
44F	ARANDELA	✓	✓	R-TIDE2-ARAND-44F
44H		✓	✓	R-TIDE2-ARAND-44H
46A		✓	✓	R-TIDE2-CAND-46A
46B		✓	✓	R-TIDE2-CAND-46B